

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0001	03-01-3215	ARMATURE, WITH SILVER CONTACT FOR IND SELECTOR U/W INTLKG MACH	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 2634-4 GR1.				
0002	03-01-3235	ARMATURE, FOR IND AND SAFETY, MAGNET, U/W MOD. 2 INTLRG. MACH.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 3101-4 GR1				
0003	03-01-4925	BELL, 24 VOLTS, VIBRATING, USED WITH NX CONTROL MACHINE #55500-34	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 53938-020-00				
0004	03-01-5055	BLOCK, END FOR THREE TIER CONTROLLER U/W INTLKG MACHINE	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 2565-13 PL.60409, FIG. 2				
0005	03-01-5100	BLOCK, CONTACTOR, BLOCK COMPLETE FOR CONTACTOR REF-C, USED ON SWITCH MACHINES FOR BIASED-NEUTRAL CONTROLLER	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. P85-0786				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0006	03-01-5235	BLOCK, ROTARY LEVER LOCKING, W/METAL HANDLE U/W CONTROL PANEL, "RED" DYED	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 59774-6							
0007	03-01-5495	BLOCK, CONTACT W CONTACTS FOR 5 TIER SW CONTLLR U/W MOD 2 INTLKG MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 3253-17 GR1							
0008	03-01-5650	BLOCK, CONTACT W CONTACTS FOR SCREW RELEA SE, U/W MOD 5E INTLKG MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 54488-GR1							
0009	03-01-7695	BUTTON, PUSH, COMP. ALARM CUT-OFF USED WITH CONTROL MACH.,	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55007-26 GR.1							
0010	03-01-7700	BUTTON, PUSH, COMPLETE, W/ARROW POINTING RIGHT, EXIT PB, U/W CONTROL MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55816-15 GR.63							
0011	03-01-7702	BUTTON, PUSH COMPL. CALL-ON M.C. AIR, POWER, GROUND, U/W CONTROL MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55007-025-01							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0012	03-01-7755	PUSHBUTTON, COMPLETE, YELLOW, FOR CALL-ON,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 55007-30 GR4				
0013	03-01-7757	PUSHBUTTON, FOR EMERG. RELEASE,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 55007-30 GR2				
0014	03-01-7760	BUTTON, COMPL. BLACK, F/CALL-ON PUSH BUTTON, NX CONTROL PANELS, PLATE T-0221, REF. 16B,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 55628-34-GR.1				
0015	03-01-7761	BUTTON, GREEN WITH RH ARROW INSERT, FOR USE ON CITY HALL MODEL BOARD,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 54722-004-10				
0016	03-01-7762	BUTTON, YELLOW WITH R.H. ARROW INSERT, FOR USE ON CITY HALL MODEL BOARD,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 54722-004-11				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0017	03-01-7763	BUTTON, ORANGE, W/ RH ARROW INSERT, FOR USE ON CITY HALL MODEL BOARD	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	54722-004-12		
0018	03-01-7764	BUTTON, GREEN, PLAIN, FOR USE ON CITY HALL MODEL BOARD,	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	54722-4 GR .10		
0019	03-01-7810	BUZZER, 12 VOLT,	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	31888-014-00		
0020	03-01-8650	CLIP, FUSE 0-30A 250V ONLY FOR TERM BOARD U/W MOD. 2 INTLKG MACH.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	0838-5		
0021	03-01-9310	COMMUTATOR 194 DEG SEGMENT F/ROTARY CIR. CONTLLR. U/W INTLKG. MACH	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	28342-13 GR5		
0022	03-01-9640	CONTACT, ELECTRICAL F FD LEV LOCK AND LATCH CIR CONTLLR. U/W INTLKG. MACH	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	368042-GR2		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0023	03-02-0460	CRANK FOR HAND SCREW RELEASE U/W INTLKG MACH	EA		00		00		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.			54487-GR1			
0024	03-02-1570	50965-2 FINGER, SILVER CONTACT, FOR ROTARY, CIR. CONTROLLER, GR. 1, PL. G-0412, FIG. 6	EA		00		00		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.			50965-2GR1			
0025	03-02-2150	GEAR, 2ND COMPL FOR TIME CONTACTOR U/W IN TLKG MACH	EA		00		00		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.			46105-3GR1			
0026	03-02-2300	GRIP, LEV DOWN TURNED W LATCH PIN SPRING	EA		00		00		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.			56927-GR2			
0027	03-02-2310	GRIP, LEV TURNED W LATCH PIN SPRING U/W	EA		00		00		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.			56927-4GR1			

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0028	03-02-2860	HANDLE, UPTURNED, COMPLETE.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56927-2, GR 1, PL G0315							
0029	03-02-3400	INSERT, DOT, FOR INTERLOCK MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56985-62							
0030	03-02-3401	INSERT, BAR, FOR INTERLOCK MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56985-63							
0031	03-02-3402	INSERT, ARROW, FOR INTERLOCK MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56985-64							
0032	03-02-3875	KEY, TO UNLOCK BRAKE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 53763-006-00							
		N P ALSTOM SIGNALING, INC. PL J-2102, FIG. 55							
0033	03-02-5870	LINK, F CRANKS OF ROTARY CIR CONTROLLER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. PL G0412 FIG. 27							
		N D ALSTOM SIGNALING, INC. 53408-1							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0034	03-02-5960	LOCK, NYLON PUSH BUTTON U/W PUSH BUTTON ON CONTROL PANEL RED DYED	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 58515-001-00				
0035	03-03-7755	SPRING, FOR CONTACT ARM, LEV LOCK U/W INTLKG MACH	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 36807				
0036	03-03-8305	SPRING, CONTACT, F SIG HV CIR CONTLLR MADE FROM N OR R IND TO FULL N OR R U/W INTLKG MACH	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 2566-3				
0037	03-03-8420	SPRING, CONTACT F SW LEV HV CIR CONTLLR MADE FROM U OR R IND TO FULL U OR R 2 U/W INTLKG MACH	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 2566-2				
0038	03-04-0158	SWITCH COMPLETE, 2 POS. L.H. 45 DEG. & R.H. SIGNAL U/W CONTROL MACH.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 55330-012-22				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0039	03-04-0159	SWITCH, COMPLETE, 2 POS. 90 DEG	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	55330-9-GR7		
0040	03-04-0170	SWITCH, ROTARY F DIMMER CONTROL U/W NX CONTROL PANEL	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	55330-32-GR1		
0041	03-04-0172	SWITCH, COMPLETE, LINE TRANSFER, U/W CONTROL MACH.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	55330-32-GR2		
0042	03-04-0188	SWITCH, COMPLETE, 90 DEG. L.H. ROT. SIGNAL U/W CONTROL MACH.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	55330-35-GR2		
0043	03-04-0190	SWITCH, COMPLETE, SNOW MELTER, U/W CONTROL MACH.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	55330-36-GR1		
0044	03-04-0200	SWITCH, CAM LEVER, FOR STARTING LIGHTS CONTROL BOX, OPERATING ROOM EQUIPMENT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	56970-002-00		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0045	03-04-0255	SWITCH, PUSH-PULL, ROTARY, SPRING TYPE, FOR GRS TYPE "C" CONTROL MACHINE	EA		00		00		00
		RETURN TO CENTER POSITION, PLUG-IN AND MAINTAINERS PANEL							
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 30731-000-01							
0046	03-04-0280	SWITCH PUSH-PULL, ARROW RIGHT 90 DEG. 54603-10-GR8 & KNOB #54722-4-GR1, & & WASHER #53029-27, & INSULATOR	EA		00		00		00
		RH ROTATION SIG ENT LEV. W/JOCKET INDICATOR #54605-3-GR1, & SCREW #55854 #37412-222 U/W NX CONTROL MACH.							
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 55330-030-03							
0047	03-04-0285	SWITCH, PUSH-PULL, ARROW LEFT 90 DEG. WITH NX CONTROL MACH	EA		00		00		00
		LEFT HAND ROTATION SIG, ENT.LEV, USE							
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 55330-030-04							
0048	03-04-0295	SWITCH, PUSH-PULL ARROW RIGHT NON	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55330-31GR+4							
0049	03-04-0315	SWITCH PUSH-PULL NON-ROTATING EMER. SW REL U/W NX CONTROL MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55330-34-GR4							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0050	03-04-0440	TERMINAL, U/W REACTOR BOND, FOR TWO 500 MCM CABLE.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 44625-1							
0051	03-04-0450	TERMINAL, U/W REACTOR BOND, FOR FOUR 500 MCM CABLE.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 44623-1							
0052	03-05-0100	RELAY, "J", 180/180 OHMS, 6FB NEUTRAL FOR NX & CODING NETWORKS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 31500-000-01							
0053	03-05-0300	RELAY, M5 SWITCH-OVERLOAD NEUTRAL, 2FB (FRONT/BACK) MAKE-BEFORE-BREAK CONTACTS ARRANGEMENT. NOMINAL RESISTANCE 1000 OHM, MAX. EACH RELAY MUST INDIVIDUAL PACK TO	EA		02		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56001-981-01							
0054	03-05-0305	RELAY, B1 LINE 928-01 BIASED-NEUTRAL, 2FB-3F-3B CONTACTS ARRANGEMENT, PICKUP AND WORKING AMPERES 0.0088. PREVENT DAMAGE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56001-928-02							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0055	03-05-0500	RELAY, TYPE JT, 24 VOLT	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 31580-000-01				
0056	03-05-1720	RELAY	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 56007-69GR1				
0057	03-05-1723	RELAY, TYPE B2 TIME ELEMENT.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 56007-71-GR1				
0058	03-05-2890	RELAY, TYPE B2, TIME ELEMENT	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 56007-066-01				
0059	03-05-2900	RELAY, TYPE B2 TIME ELEMENT, 110V, 60H2,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 56007-068-01				
0060	03-05-2910	RELAY, TYPE B2, TIME ELEMENT, 110V, 60HZ 2-45 SEC.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 56007-067-01				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0061	03-05-2950	RELAY, TYPE B2, 60HZ, TIME ELEMENT AC MICROCHRON II	EA		258		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 50800-103-01							
0062	03-05-2960	RELAY, TYPE B2 25HZ MICROCHRON II TIMER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 50800-104-01							
0063	03-05-3000	RELAY, AC 60 CYCLE TYPE B2V TRACK RELAY 4F-4B WITH SHOCK SENSOR	EA		05		28		15
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56005-100-22							
0064	03-05-3200	RELAY, AC 60CY TYPE L LINE 2POS 1EL VANE 6F-2B 110V	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 51535-1GR1							
0065	03-05-5100	RELAY, DC TYPE B1, 2 POS POLAR STICK 520 OHM 12V 2NR DC GRD DET	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56001-675-01							
0066	03-05-5150	RELAY, DC TYPE B1 2 POS NON-BIASED .068-230 OHM 10V 2FB-M-B-B SW CONT. OL	EA		00		00		00

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
		OVER-LOAD							
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56001-785-01							
0067	03-05-5190	RELAY, DC TYPE B1 2 POS ORD. BIASED 330 OHM 12 V 6FB-S-S-M-D PANEL LTS DIM OFF	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56001-785-GR33							
0068	03-05-5200	RELAY, D.C., TYPE B1, 2 POS.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56001-785-91							
0069	03-05-5250	RELAY, DC TYPE B1 2 POS COUNT WEIGHT BIASED NUT 1 OHM 12V 6FB RECT CHG.	EA		02		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56001-922-10							
0070	03-05-5260	RELAY, B1 SPU	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56001-911-01							
0071	03-05-5400	RELAY, DC TYPE B2 POSITION, 75 CYCLE CODER, 150 OHM 12V 2F-2B SILVER DC GRADE DETECTOR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 31750-101-05							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0078	03-05-7016	RELAY, DC TYPE VTA 2 POS, POLAR BIASED 900-900-OHM 4FB	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 59300-103-GR5							
0079	03-05-7050	RELAY, VTB CLASS S SINGLE ARMATURE COIL RES. 34	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 59301-101-GR8							
0080	03-05-7200	X-PAK, U/W VTB RELAY 40-45 PULSES	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 30733-001-01							
0081	03-06-0450	ARMATURE, COMPLETE U/W TYPE VTA RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 18472-2 GR1							
0082	03-06-0710	ARMATURE, FOR TYPE B2 TIME RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 59741-1 GR.1							
0083	03-06-1910	BEARING, JEWELLED, COMPLETE, FOR TYPE "B2" AC RELAY	EA		150		100		1,160
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 51527-001-03							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0084	03-06-1962	BEARING, UPPER, FOR B2 MECHANICAL CODER TRANSMITTER RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 57092-009-01							
0085	03-06-1964	BEARING, LOWER, FOR B2 MECHANICAL CODER TRANSMITTER RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 57092-008-01							
0086	03-06-2570	BLOCK, RETAINING F SPRINGS OF MASTER RLY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 54527-1							
0087	03-06-3460	BUSHING, INSULATES CONTRACT- TERMINAL POST 2B RLY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 35287							
0088	03-06-3803	CAM, LOWER, FOR B2 MECHANICAL CODER TRANSMITTER RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 58728-001-01							
0089	03-06-3805	CAM, UPPER, FOR B2 MECHANICAL CODER TRANSMITTER RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 58728-001-02							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0090	03-06-4980	CLIP, FOR B2V CONTACT GROUP PUSHER	EA		00		100		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56025-000-00							
0091	03-06-6435	CONTACT, ELECTRICAL UNIV. FOR CONTACT GR, USED WITH L OR 2A RELAY	EA		485		500		400
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 42799-007-08							
0092	03-06-6450	CONTACT, CARBON, UNIV, FOR CONTACT GR 2A-B RELAY	EA		00		500		400
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 42799-007-10							
0093	03-06-7025	CONTACT, GROUP, COMPLETE, 2F 1B USED WITH B1-B2 RELAYS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56012-108-02							
0094	03-06-7260	CONTACT, GROUP, COMPLETE, FOR SPARE SPACE 2-3-4-5 RELAYS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56012-108-11							
0095	03-06-7325	CONTACT GROUP, FOR VTA RELAY QUIKODE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56012-99-GR8							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0096	03-06-7390	CONTACT GROUP COMPL, F CHECKING-CONTACT U/W B2 TIME RLY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 57265-7GR1							
0097	03-06-8425	COVER, FOR B1 RELAY TO INCLUDE 2 WASHERS AND 2 NUTS	EA		00		100		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. P62-0579							
0098	03-06-8440	COVER, F B2 POLAR NEUT. RLY.	EA		50		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56029-102-00							
0099	03-06-8450	COVER, COMPLETE, FOR B2 TIME RELAYS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 57287-002-09							
0100	03-06-8460	COVER, COMPL F B2 TK RLY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 57287-002-12							
0101	03-06-9080	PLATE CLAMPING, CODER FOR B2 MECHANICAL CODER TRANSMITTER RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55911-035-00							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0102	03-07-1135	GASKET, FOR PLASTIC COVER ON TYPE B2 TIME RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 13014-222-00							
0103	03-07-1136	GASKET, FOR BACK OF TYPE B2 TIME RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 50737-91							
0104	03-07-1137	GASKET, B2 RELAY, LEFT SIDE.	EA		00		50		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 13014-279							
0105	03-07-1138	GASKET, B2 RELAY, RIGHT SIDE.	EA		00		50		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 13014-280							
0106	03-07-1360	GEAR, COMPLETE FOR B-2 TIME RELAY 2-45 SECONDS REF. 21 ON DWG. 56007-1	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56451-1 GR-1							
0107	03-07-1361	GEAR, COMPLETE FOR 90 SEC TUPE B2 TIME	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56451-1GR2							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0108	03-07-1362	GEAR, COMPLETE FOR 22.5 SEC TYPE B2 TIME	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56451-1 GR3							
0109	03-07-1900	KIT, REBUILD, 4F/4B B2V TRACK RELAY TO INCLUDE THE FOLLOWING: 1 COVER WITH HANDLE #57287-002-12, 1 COVER GASKET #13014-222-00, 1 SHAFT #43317-012-00, 1 GASKET (LEFT) #13014-279-00, 1 GASKET (RIGHT) #13014-280-00, 4 CONTACT GROUP #56012-037-01, 4 PUSHER #55863-036-00, 4 CLIP #56025-000-00, 2 BEARING COMP #51527-001-03, 2 NUTS #12578-002-00 FOR B2V TRACK RELAY 4 FRONT/4 BACK.	EA		132		50		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 17550-117-01							
0110	03-07-1910	KIT, REBUILD, 2F/2B B2V TRACK RELAY TO INCLUDE THE FOLLOWING: 1 COVER WITH HANDLE #57287-002-12, 1 COVER GASKET #13014-222-00, 1 SHAFT #43317-012-00, 1 GASKET (LEFT) #13014-279-00, 1 GASKET (RIGHT) #13014-280-00, 2 CONTACT GROUP #56012-037-01, 2 PUSHER #55863-036-00, 2 CLIP #56025-000-00, 2 BEARING COMP #51527-001-03, 2 NUTS #12578-002-00 FOR B2V TRACK RELAY 2FRONT/2 BACK.	EA		368		08		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 17550-117-02							
0111	03-07-3102	MAGNET, LOC.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 51508-10 GR3							
0112	03-07-3350	MOTOR COMP. F B2 TIME RLY 2 TO 45 SEC.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56108-191-01							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0113	03-07-3352	MOTOR, COMP. U/W 25 CYCLE B2 TIMER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56108-191-03							
0114	03-07-3360	MOTOR, COMP F B2 TIME RLY 4 TO 90 SEC REF 47 DWG 56007-1	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56108-191GR2							
0115	03-07-3362	MOTOR, COMP. U/W 25 CYCLE B2 TIMER DWG. 56007-62 GR. 1 4 - 90 SEC.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56108-191-GR4							
0116	03-07-5760	NUT, 1F4-28- HEX LOCKS KNURLED NUT U/W B RLYS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 01472-008-00							
0117	03-07-7265	PIN, SPLIT FOR RELAY VANE SHAFT.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 17188-31							
0118	03-07-8860	PLATE, REGISTRATION FEMALE FOR B2V60 CYCLE TRACK RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 58879-4 GR. 1							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0119	03-08-0230	PUSHER, FOR B2V CONTACT GROUP	EA	200	204	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	55863-036		
0120	03-08-0622	RECTIFIER, W/NUT #01272-7 & WASHER 53029	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	29174-24		
0121	03-08-0680	RIBBON, CODER, FOR B2 MECHANICAL CODER TRANSMITTER RELAY	EA	15	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	22148-000-02		
0122	03-08-1205	ROTOR, SHAFT, COMPLETE, FOR B2 MECHANICAL CODER TRANSMITTER RELAY	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	57094-010-01		
0123	03-08-1250	ROTOR ASSEMBLY FOR B2 CODER RELAY TO INCLUDES THE HUD, SHAFT AND PIN	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	P62-0603		
0124	03-08-5540	SHAFT, FOR B2 TRACK RELAY	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	43317-012-00		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0125	03-08-7110	SPRING, CODER, FOR B2 MECHANICAL CODER TRANSMITTER RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 51055-008-00							
0126	03-08-9490	TAG, 1C FOR RELAY.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 34558-035							
0127	03-08-9508	TAG, 7C, FOR RELAY.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 34558-041							
0128	03-08-9641	TAG, 3R UW 2A RLY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 34558-128							
0129	03-09-0600	VANE, COMPLETE, FOR B2 TRACK RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 17550-129-01							
0130	03-09-0695	VANE, COMPLETE, USED WITH B2 TRACK RELAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 17550-129-02							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0131	03-09-1025	WASHER, 1/4" ID X 9/16" OD, .040, FOR TERMINAL POSTS	EA	40,000	40,000	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	01225-002-00		
0132	03-12-0340	ARM, CONTACT, COMPLETE, FOR M-5 SWITCH 7B CIRCUIT CONTROLLER (LONG)	EA	00	139	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	35466-011-02		
0133	03-12-0350	ARM, CONTACT COMPLETE FOR M5 SWITCH 7B CIRCUIT CONTROLLER (SHORT)	EA	00	246	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	35467-010-02		
	Y	P	ALSTOM SIGNALING, INC.	35467-10GR2		
0134	03-12-0375	ARM, CONT FINGER COMP U/W 7B SW C-CONT	EA	00	230	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	35490-009-02		
0135	03-12-0500	ARM, USED WITH 5 SWITCH MACHINE OPERATING YOKE OF POLE CHANGER	EA	25	75	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	45579-000-00		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0136	03-12-0535	ARM, U/W 5 SW MACH F ARM OPERATING POLE C HANGER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45590-2 PL J2106							
0137	03-12-0560	ARM, COMPLETE, USED WITH 5 SWITCH MACHINE FOR OPERATING POLE CHANGER	EA		15		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45680-003-01							
0138	03-12-0580	ARM, USED WITH 5 SWITCH MACHINE, COMPLETE, OPERATES CONT BLOCK POLE CHANGER.	EA		25		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 51106-000-01							
0139	03-12-0865	ARMATURE, COMP. FOR MOTOR 5 SW. MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45631-7GR1							
0140	03-12-0960	PIN, BALL, FOR CRANK ON CIRCUIT COMPTROLLER.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 43206-003-00							
0141	03-12-0963	BALL, PIN COMPLETE WITH OILER FOR SWITCH CIRCUIT CONTROLLER CONNECTING	EA		00		00		00

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
		ROD				
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 43206-6				
0142	03-12-1125	BAR, CAM, COMPLETE, WELDED, USED WITH 5 SWITCH MACHINE	EA	13	10	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 45523-001-01				
0143	03-12-1195	BAR, THROW, LEFT HAND, USED WITH 5 SWITCH MACHINE	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 45670-000-00				
0144	03-12-1215	BAR, THROW, RIGHT HAND, USED WITH 5 SWITCH MACHINE	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 45671-000-00				
0145	03-12-1250	BAR, 3 WAY GUIDE U/W 7B SW. CIR. CONTLLR	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 53989-1GR1				
0146	03-12-1300	BARREL, LOCK FOR M-5 SWITCH DETENT BRAKE	EA	00	30	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 54382-000-00				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0147	03-12-1430	BASE, FOR CONTACT BLOCK, M-5 SWITCH POLECHANGER	EA		25		40		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 56524-001-02							
0148	03-12-1605	57603, GR. 2 BASE, FOR SWITCH MACH. DRILLING DIAGRAM 53665-5, FOR 23 INCH TIE SPACING AND 7 INCH TIE PLATE -BMT NO. 6- PLATE J-2104, FIG. 46	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 57603-GR2							
0149	03-12-1612	BASE, GRS FOR #5 SWITCH MACHINE R OR LH WITH TAPPED HOLES IN MOUNTING LUGS ON BOTH SIDES OF BASE, T.A. ELECTRIC SKETCH #7502-1 SWITCH MACHINE STANDARD BASE, GRS	EA		10		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 49413-013-00							
0150	03-12-1805	BEARING, COMP. FOR UH INSUL. FRONT ROD	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 31207-GR2							
0151	03-12-1870	BEARINGS, 45642-6, MOTOR, PL. J-2114, FIG. 27	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45642-6							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0152	03-12-2125	BLOCK	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 1544-9							
0153	03-12-2210	BLOCK, CONTACT, COMPLETE FOR POLE CHANGER YOKE ON M5 SWITCH MACHINE.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 54027-5-GR-1							
0154	03-12-2220	BLOCK, CLAMPING, FOR CAM ACTUATED BREAKER, FOR AUTOMATIC TRAIN STOP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 17745-045-00							
0155	03-12-2335	BLOCK, CONT F PC W FASTELL CONT UW 5 SW M ACH REF 21 45514-5	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45589-9 REF 21							
0156	03-12-2415	BLOCK, FILLER TIE PL TO SW MACH UW 5 SW MACH REF 7 51139-588	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 51978-1							
0157	03-12-2700	BOARD	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 35460-2							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0158	03-12-2970	BOLT, EYE, 3/8"-16 X 2-1/2" LONG, WITH A 1/4" X 1-3/8" LONG PIN FOR COVER ON COMMUTATOR OF M5 SWITCH MACHINE	EA		04		08		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45654-001-00							
0159	03-12-3650	BOLT, 1/2" X 2-1/4" SQUARE HEAD NUT (#38931-002-00), COTTER PIN USED WITH SWITCH BOX ROD IN SWITCH (#49527-006-00), WITH THE FOLLOWING, (#00041-000-ON), WASHER (#01273-010-ON) LAYOUT.	KT		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. P91-0140							
0160	03-12-4165	BOLT, 3/4-10 X 3 IN. LONG, HEX HEAD	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 00894-020-00							
0161	03-12-4166	BOLT, 3/4 IN. - 10 X 4 IN. HEX. HD., F/SW., HOLD DOWN CLAMPS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 00894-047-00							
0162	03-12-4168	BOLT, 3/4 IN. - 10 X 6 IN., HEX. HD., F/SW. HOLD DOWN CLAMPS.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 894-38							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0163	03-12-4170	BOLT, 3/4-10 X 2-1/2 IN. HEX HD.	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
0164	03-12-4725	BOX, TOOL, FOR SWITCH MACHINE	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
0165	03-12-4925	BRACKET	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
0166	03-12-4945	BRACKET, FOR POLE CHANGER, U/W 5SW	EA		00		15		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
0167	03-12-5015	BRACKET, FOR SUPPORTING GUARD U/W 5 SW	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
0168	03-12-5200	BRAKE, ELECTRO-MAGNETIC, FOR MOTOR	EA		00		00		00
		COMPLETE, WITH INSULATED BINDING POST							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
		NUTS, FOR MODEL 5 SWITCH MACHINE COMPLETE.				
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 45630-17				
0169	03-12-5350	BRUSH, 1-7/32" WIDE X 3/8" THICK X 2" LONG, FOR SWITCH MOTOR MODEL 5 SWITCH	EA	100	50	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 00566-006-00				
0170	03-12-5465	HOLDER, BRUSH, COMPLETE, FOR MOTOR M-5 SWITCH MACHINE	EA	00	09	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 01550-002-01				
0171	03-12-5600	BUSHING, COMPLETE FOR M-5 SWITCH MACHINE DETENT BRAKE	EA	15	55	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 33760-001-01				
0172	03-12-5740	BUSHING, INSULATING, FOR BOLT	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 7350-64				
0173	03-12-5820	BUSHING, FIBRE, INSULATES BALL PIN OF 7B SW CC.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 43207-000-00				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0174	03-12-5870	BUSHING, POLE CHARGER, USED IN MS SWITCH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 07350-291-00							
0175	03-12-5960	BUTTON, COMPLETE, FOR ALL MODEL 5 SWITCH MACHINES	EA		10		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 51142-006-01							
0176	03-12-6120	CAM	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45601							
0177	03-12-6140	CAM, COMPLETE, RIGHT HAND, USED WITH 4-WAY 7B SWTCH C	EA		00		80		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 46808-002-01							
0178	03-12-6150	CAM, COMPLETE, LEFT HAND, CIRCUIT CONTROL BOX.	EA		00		40		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 46809-002-01							
0179	03-12-6475	CAP, COMPLETE FOR FRICTION CLUTCH U/W 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56934-GR3							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0180	03-12-6850	CASE, COMPL. F/ 7B 4 WAY SW. CIR. CONTROLLER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 38638-8GR5 PLK0136							
0181	03-12-6875	CASE, COMPLETE W/BUSHINGS FOR 7B 6 WAY SW. CIR. CONTROLLER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 38497-1GR15							
0182	03-12-6895	CASE, F. FRICTION CLUTCH UW.5, SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45556-000-00							
0183	03-12-7145	CLAMP, & BAR, COMPLETE, FOR CLAMPING MODEL 5 SWITCH MACHINES TO 6" X 8" TIES, CONSISTING OF: STRAP #51432-166, CLAMP #52929-10, NUT #53432-30, BOLT #894-38, NUT #0272-9, WASHER #493-269, BUSHING ,7350-283, WASHER #35703-3, WASHER #1273-13-ON	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 42849-002-05							
0184	03-12-7510	CLUTCH, FRICTION COMPLETE U/W M-5 SW MACHINE WITH GEARS AND WOODRUFF KEY	EA		00		05		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 59649-091-01							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0185	03-12-7750	COIL, MAG FOR PC UW 5 SW MACH	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. Z1623-9GR1				
0186	03-12-7770	COIL	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 38451-006-01				
0187	03-12-8000	CONDUIT, BETWEEN FRAME-MOTOR UW 5 SW MACHINE	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 42087-005-00				
0188	03-12-8020	CONDUIT, F LEAD UW 5 SW MACH.,	EA	05	05	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 45540-000-00				
0189	03-12-8790	CONTROLLER, SWITCH CIRCUIT, 7B 6 WAY 3 POSITION 6N, 6R CONTS. EXCEPT TO BE EQUIPPED W/CRANK, COMPLETE, DWG. 38660-13, BALL PIN #43206-6 WITH 67-1/2 DEG. ALEMITE OILER	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 53530-015-02				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0190	03-12-8798	CONTROLLER, SWITCH 4 WAY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 53530-033-01							
0191	03-12-9000	CORE, COMPLETE, FOR PC COILS UW 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 50598-000-02							
0192	03-12-9010	CORE, FOR PC COILS UW 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 50598-002-01							
0193	03-12-9250	COUPLING, FOR CONDUIT	EA		05		05		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45685-001-00							
0194	03-12-9285	COUPLING, COMPLETE FOR CONDUIT UW 5 SW MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45687-003-00							
0195	03-12-9310	COUPLING, F11F2 FLEX CONDUIT UW 7B SW CO	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45688-92-GR2							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0196	03-12-9650	COVER, COMPLETE, FOR 7B- 4 WAY SWITCH CIRCUIT CONTROLLER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 38639-2 GRADE 3							
0197	03-12-9660	COVER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 38639-2GR7							
0198	03-12-9695	COVER, COMPLETE WO GUARDS UW 5 SW MACHINE	EA		05		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45520-018-01							
0199	03-12-9750	COVER, FOR PC W FASTELL CONT UW 5 SWITCH MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45571-27							
0200	03-12-9795	COVER, FOR MOTOR UW 5 SW MACHINE	EA		00		06		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45655							
0201	03-12-9850	COVER, COMPLETE WITH GASKET FIG. 17 AND HINGE STUDS FIG. 77 FOR MOTOR, FOR	EA		01		01		00

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
		SWITCH MACH. PL. J-2114, FIG. 8				
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 52318-009-03				
0202	03-12-9875	COVER, COMP. F BRAKE U/W 5. SW MACH.	EA	02	01	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 52318-044-01				
0203	03-13-0295	CRANK ONLY UW 7B SWITCH CIRCUIT CONTROLLER	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 38661-015-00				
0204	03-13-0355	CRANK, FOR HAND OPERATION UW 5 SW MACHINE	EA	56	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 54477-000-01				
0205	03-13-0575	DETENT, COMPLETE, WITH ELKONITE CONTACTS, USED WITH 5 SWITCH MACHINE SWITCH MOTOR,	EA	00	05	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 09040-002-01				
0206	03-13-0600	DETENT, COMPLETE, FOR MODELS 5E, 5F, 5G, 5H SWITCH MACHINES	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. P85-981				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0207	03-13-0700	DISC, STEEL REVOLVING F CLUTCH, UW 5 SW MACH.,	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	45557-000-00		
0208	03-13-0750	DISC, STEEL F CLUTCH UW 5 SW MACHINE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	45558-000-00		
0209	03-13-0765	DISC, FOR FRICTION CLUTCH, M-5 SWITCH MACHINE, HARD BLACK VULCANIZED FIBRE.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	45562-001-00		
0210	03-13-0775	DISC, STEEL BACKING F CLUTCH UW 5 SW MACH INE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	45563-000-00		
0211	03-13-0795	DISC, BRONZE, FIG.12, GENUINE GENERAL RAILWAY SIGNAL CO.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	53924-4 PL J2112		
0212	03-13-0985	DOG, LOCK ROD, AS SHOWN FOR CAM BAR, FIG B.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	45600-9		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0213	03-13-1755	FRAME, SUPPORTS FRICTION CLUTCH USED WITH 5 SW. MACHINE, PL. J2104 FIG. NO. 4 -	EA	02	10	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	45551-001-00		
0214	03-13-1805	FRAME, LOCKING, STRIPPED, USED WITH 5 SWITCH MACHINE	EA	06	15	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	49415-000-00		
0215	03-13-2148	GASKET, F COVER 5 SW MACHINE MOTOR	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	13014-136-00		
0216	03-13-2420	MAIN GEAR, ONLY, FIG. F, PLATE J-2106, FIG. 18	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	45532-000-00		
0217	03-13-2450	GEAR, BEVEL, USED WITH 5 SWITCH MACHINE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	45535-000-00		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0218	03-13-2480	GEAR, MAIN, COMPLETE, USED WITH 5 SWITCH MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 51140-010-01							
0219	03-13-2500	GEAR, AND FRAME, COMPLETE ASSEMBLY, USED WITH 5 SWITCH MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 57932-000-01							
0220	03-13-2670	GIB, R.H. FOR MODEL 5 SWITCH MACHINE	EA		100		05		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 11072-005-00							
0221	03-13-2675	GIB, LEFT HAND, FOR GUIDE ON THROW BAR, USED WITH 5 SWITCH MACHINE BRONZE	EA		100		05		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 11072-006-00							
0222	03-13-2905	GUARD, F LOCKROD AND THROW BAR 5 SWITCH MACHINE 22 INCH CENTERS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 51114-16							
0223	03-13-3185	GUIDE, COMPLETE FOR CONTRACT ARM UW 7B 6 WAY SW CC NEW STYLE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 53988-1-GR1							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0224	03-13-3200	GUIDE, COMPLETE, FOR THROW BAR CUT ON SIDE FOR GIBS, USED WITH 5 SWITCH MACHINE, WITH BRONZE GIB	EA		00		105		12
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 58918-000-01							
0225	03-13-3395	HASP, FOR BRAKE COVER 5 SW MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 16110-12							
0226	03-13-3425	HASP, FOR BRAKE COVER UW SW MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 29485							
0227	03-13-3835	JAW, SOLID 1 1F4 BUTT UW SW OR STOP LAYOUT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 103-1							
0228	03-13-3855	JAW, SCREW FOR FRONT ROD UW SW LAYOUT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 959							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0229	03-13-3880	JAW, SCREW 1-1/4 WI BUTT W PIN UW SWITCH	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 4203				
		N P ALSTOM SIGNALING, INC. D-0805.FIG.F.				
0230	03-13-3920	ROD	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 109-5				
0231	03-13-3930	ROD	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 30584GR1				
0232	03-13-3955	JAW, FOR SWITCH BOX ROD - COMPLETE WITH BOLT	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 43054-001-00				
0233	03-13-4300	LAYOUT, SINGLE SWITCH L.H., WITH BASE 49413-13, W/SW. MACH. OPPOSITE EA		00	00	00
		SIDE OF 3RD RAIL COMPLETE,				
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 51139-675-GR1				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0234	03-13-4301	LAYOUT, SINGLE SWITCH, R.H. WITH BASE #49413-13, WITH SWITCH MACHINE OPPOSITE SIDE OF THIRD RAIL, COMPLETE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 51139-675-GR2							
0235	03-13-4304	SWITCH, MACHINE, M-5, LEFT HAND, WITHOUT LAYOUT	EA		06		03		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45506-011-01							
0236	03-13-4305	SWITCH, MACHINE, M-5, RIGHT HAND WITHOUT LAYOUT	EA		10		03		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45506-011-02							
0237	03-13-4310	MOTOR, MODEL 5 SWITCH, COMPLETES WITH CUTOUT ASSEMBLY, MAGNETIC HOLDING DEVICE, MOTOR AND FRICTION CLUTCH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45630-022-02							
0238	03-13-4425	LEAD, M5 WIRE HARNESS COMPLETE FOR MOTOR TO POLE CHANGER	EA		00		13		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45621-007-01							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0239	03-13-4635	LETTER, CAST IRON, -A- 3", USED WITH 5 SW. MACHINE., BMT E.N.Y. ONLY	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. J2309 FIG 35							
		N D ALSTOM SIGNALING, INC. 31760-60							
0240	03-13-4640	LETTER, CAST IRON B 3" USED WITH 5 SWITCH MACHINE BMT ENY ONLY.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. J2309 FIG							
		N D ALSTOM SIGNALING, INC. 31760-26							
0241	03-13-4660	LETTER, CAST IRON, 3", GRS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. J2307 FIG.39							
		N D ALSTOM SIGNALING, INC. 31760-49							
0242	03-13-4693	LETTER, N CAST, IRON 3" HIGH FASTENS TO CROSS TIE TO IDENTIFY NORMAL SWITCH POINT ON POWER OPERATED TRACK SWITCHES	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 31760-24							
0243	03-13-4697	LETTER, "R" CAST IRON 3" HIGH FASTENS TO CROSSTIE TO IDENTIFY REVERSE SWITCH POINT ON POWER OPERATED TRACK SWITCHES	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 31760-25							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0244	03-13-4895	LEVER, FOR RELEASING BRAKE, USED WITH 5 SWITCH MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 53936-2							
0245	03-13-5785	LUG, HINGE FOR MOTOR COVER, USED WITH 5 SWITCH MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45650-003-00							
0246	03-13-6300	MAGNET, STATIONARY WITH STUDS FOR M5 SWITCH DETENT BRAKE ON M5 SWITCH MOTOR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 09037-001-03							
0247	03-13-6302	MAGNET, ROTATION, WITHOUT STUDS, FOR M5 SWITCH DETEND BRAKE IN M5 SWITCH MOTOR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 09032-001-03							
0248	03-13-6868	FIGURE, "1", 5", HIGH WITH RIVETS USED WITH 5 SW MACH., 1	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 31760-1							
0249	03-13-6874	NUMBER, CAST IRON, 5 INCH HIGH W/RIVETS USED WITH 5 SW. MACH. (3)	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 31760-003-00							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0250	03-13-7050	NUT, ADJUSTING F CLUTCH UW5 SW MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45559-002-00							
0251	03-13-8210	NUT, 5/8-11 HEX, 3/8 THICK "F" BALL PIN USED WITH 7B CIR CONTLLR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 50748-005-00							
0252	03-13-8220	NUT, 5/8-11 HEX HOLDS MOTOR TO ADAPTER USED WITH 5 SW MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 14070-1							
0253	03-13-8645	NUT, INCH-8 HEX, HOLDS MAIN GEAR USED WIT H 5 MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 00477-000-ON							
		N P ALSTOM SIGNALING, INC. J-2104 FIG.32							
		N P ALSTOM SIGNALING, INC. J-2807 FIG.2							
0254	03-13-8745	NUT, 1-1/4" X 7, HEX, FOR THROW ROD, USED WITH SW. LAYOUT.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 00545-007-00							
		N P ALSTOM SIGNALING, INC. J2809 FIG.2							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0255	03-13-8765	NUT, 1 1/4-7 HEX FOR LOCK ROD USED WITH SW LAYOUT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 02813-003-00							
0256	03-13-8785	NUT, ADJUSTING, 1-1/4- #- 7	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 44921							
0257	03-13-9390	PIN, COMPLETE, W/OILER FITTING NO. 34232-17 AND COTTER NO. 44, FOR LOCK ROD ON MODEL 5 SWITCH MACHINE,	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 730-111-00							
0258	03-14-0240	PIN, USED WITH 5 SW MACHINE FOR MAIN GEAR STUD	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 33397-6							
0259	03-14-0550	PINION, FOR SHAFT MAIN GEAR USED WITH 5 SW MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45533							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0260	03-14-0560	PINION, FOR FRICTION CLUTCH, USED WITH 5 SWITCH MACHINE, GRS DWG.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45533-8							
0261	03-14-0570	PINION, FOR SHAFT BEVEL GEAR UW 5 SW MACH. G.R.S.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45534							
0262	03-14-0790	PLATE, FOR MOUNTING 7B 4 WAY SW CIR CONTLLR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 00559-017-00							
0263	03-14-0797	PLATE, WASHER FOR SW FRONTED	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 05656-017-00							
0264	03-14-0800	INSULATION, PLATE, RH. OR LH. FOR FRONT ROD	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 6794-15							
0265	03-14-0808	PLATE, INSULATING FOR FRONTED SWITCH LAYOUT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 30220-12							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0266	03-14-0830	PLATE, INSULATION FOR BRAKE U/W 5 SW MACH NX	EA		00		00		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.			30220-128			
	N	D	ALSTOM SIGNALING, INC.			54188-4			
0267	03-14-0890	PLATE, BEARING, FOR MAIN GEAR U/W 5 SW MACH	EA		00		00		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.			45537			
0268	03-14-0910	PLATE, FOR WIRE INLET U/W 5 SW MACH	EA		00		00		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.			45555			
0269	03-14-0970	PLATE, INSULATION FOR FRONT ROD U/W SW LAYOUT	EA		00		00		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.			47409			
0270	03-14-1030	PLATE, WEARING CAMBAR, USED WITH 5 SWITCH MACHINE	EA		10		10		00
	QPL	CODE	MFG - NAME			MFG - PART-NO			
	Y	P	ALSTOM SIGNALING, INC.			54920-010-01			

MATERIAL STANDARDS USAGE REPORT


REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0271	03-14-1556	PLUNGER, SQ CUT END-F-PC U/W 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 31393-12							
0272	03-14-1810	CHANGER, POLE, COMPLETE WITH FASTELL CONTACTS, USED WITH MODEL 5 SWITCH MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45514-007-01							
0273	03-14-2245	POST, TERM WITH BRACKET ONLY FOR POLE CHANGER WITH FASTELL CONT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 51198-9 GR1							
0274	03-14-2835	ROCKER, OPERATES POLE CHANG ARM U/W 5 SW MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45605							
0275	03-14-3020	ROD, ONLY SOLID JAW 3FT 3" U/W SW LAYOUT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 120-9							
0276	03-14-3310	ROD, CONNECTING, U/W MODEL 5 SW MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 31064-001-07							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0277	03-14-3345	ROD, CONNECTING U/W 5 SW MACH LAYOUT COMP 3 FT 8	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 31064-8GR1				
0278	03-14-3365	CONNECTING U/W 5 SW MACH. LAYOUT, COMP 5 FT. 10,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 31064-9 GR2				
0279	03-14-3385	ROD, CONNECTING, U/W 5 SW MACH LAYOUT COMP 2FT 9 3/4	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 48062-12 GR31				
0280	03-14-3615	ROD, SWITCH BOX, OPERATOR, FRONT, COMPLETE, L.H., GRS	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 36333-68				
0281	03-14-3617	ROD, SWITCH BOX, OPERATOR FRONT, COMPLETE, R.H.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 36333-68 GR 2				
0282	03-14-3800	ROD, LOCK, COMPLETE FOR MODEL 5 SWITCH MACHINE (UNIVERSAL)	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 45512-16-GR1				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0283	03-14-4065	ROD	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 49750-136 GR1							
0284	03-14-4275	ROD, THROW, U/W 5 SW MACH LAYOUT SOLID JAW	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 120-4							
0285	03-14-4395	ROD, GRS DWG. NO. 120-16, WITH NUT NO. 5 ROD THROW U/W 5 SW MACH LAYOUT SOLID JANCOMP 4FT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 00120-016-00							
0286	03-14-4400	ROD, THROW, U/W 5 SW MACH LAYOUT SOLID JAW	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 46890-1GR17							
0287	03-14-4415	ROD, THROW USED WITH 5 SW MACH. LAYOUT, SOLID JAW COMP. 6 FT. 5. SIMILAR TO FIG. B1	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 46890-1GR32							

USER-ID : CHU
 FILE-ID : ALSTSI24
 PROG-ID : 

NEW YORK CITY TRANSIT AUTHORITY
 COMMODITY MANAGEMENT SYSTEM

PAGE : 53
 DATE : 04/12/2024
 VERSION : 1.01.00

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD																		
0288	03-14-4431	ROD, THROW, USED WITH 5 SW MACH. LAYOUT SOLID JAW COMP. 6 FT. 1, GRS.	EA		00		00		00																		
		<table border="0"> <tr> <td>QPL</td> <td>CODE</td> <td>MFG - NAME</td> <td></td> <td>MFG - PART-NO</td> </tr> <tr> <td>---</td> <td>---</td> <td>-----</td> <td></td> <td>-----</td> </tr> <tr> <td>N</td> <td>P</td> <td>ALSTOM SIGNALING, INC.</td> <td></td> <td>46890-3</td> </tr> </table>	QPL	CODE	MFG - NAME		MFG - PART-NO	---	---	-----		-----	N	P	ALSTOM SIGNALING, INC.		46890-3										
QPL	CODE	MFG - NAME		MFG - PART-NO																							
---	---	-----		-----																							
N	P	ALSTOM SIGNALING, INC.		46890-3																							
0289	03-14-4660	ROLLER, UPPER, FOR MAIN GEAR U/W 5 SW MACH	EA		00		00		00																		
		<table border="0"> <tr> <td>QPL</td> <td>CODE</td> <td>MFG - NAME</td> <td></td> <td>MFG - PART-NO</td> </tr> <tr> <td>---</td> <td>---</td> <td>-----</td> <td></td> <td>-----</td> </tr> <tr> <td>N</td> <td>P</td> <td>ALSTOM SIGNALING, INC.</td> <td></td> <td>45541</td> </tr> </table>	QPL	CODE	MFG - NAME		MFG - PART-NO	---	---	-----		-----	N	P	ALSTOM SIGNALING, INC.		45541										
QPL	CODE	MFG - NAME		MFG - PART-NO																							
---	---	-----		-----																							
N	P	ALSTOM SIGNALING, INC.		45541																							
0290	03-14-4675	ROLLER, LOWER, FOR MAIN GEAR U/M 5 SW MACH	EA		00		00		00																		
		<table border="0"> <tr> <td>QPL</td> <td>CODE</td> <td>MFG - NAME</td> <td></td> <td>MFG - PART-NO</td> </tr> <tr> <td>---</td> <td>---</td> <td>-----</td> <td></td> <td>-----</td> </tr> <tr> <td>N</td> <td>P</td> <td>ALSTOM SIGNALING, INC.</td> <td></td> <td>45541-7</td> </tr> </table>	QPL	CODE	MFG - NAME		MFG - PART-NO	---	---	-----		-----	N	P	ALSTOM SIGNALING, INC.		45541-7										
QPL	CODE	MFG - NAME		MFG - PART-NO																							
---	---	-----		-----																							
N	P	ALSTOM SIGNALING, INC.		45541-7																							
0291	03-14-4680	KIT, ROLLER REPLACEMENT, M5 SWITCH, MAIN GEAR, KIT CONSISTS OF FOLLOWING THREE ITEMS: 1 SPRING # 00786-086-00; 1 PIN # 3397-006-00; 1 WASHER #00626-025-00	EA		00		00		00																		
		<table border="0"> <tr> <td>QPL</td> <td>CODE</td> <td>MFG - NAME</td> <td></td> <td>MFG - PART-NO</td> </tr> <tr> <td>---</td> <td>---</td> <td>-----</td> <td></td> <td>-----</td> </tr> <tr> <td>N</td> <td>P</td> <td>ALSTOM SIGNALING, INC.</td> <td></td> <td>17550-200-02</td> </tr> </table>	QPL	CODE	MFG - NAME		MFG - PART-NO	---	---	-----		-----	N	P	ALSTOM SIGNALING, INC.		17550-200-02										
QPL	CODE	MFG - NAME		MFG - PART-NO																							
---	---	-----		-----																							
N	P	ALSTOM SIGNALING, INC.		17550-200-02																							
0292	03-14-5950	SCREW, 5/16-18 HEX HD 5/8 W WASH-HOLDS WASH TO FRAME 5 SW MACH.	EA		00		00		00																		
		<table border="0"> <tr> <td>QPL</td> <td>CODE</td> <td>MFG - NAME</td> <td></td> <td>MFG - PART-NO</td> </tr> <tr> <td>---</td> <td>---</td> <td>-----</td> <td></td> <td>-----</td> </tr> <tr> <td>N</td> <td>P</td> <td>ALSTOM SIGNALING, INC.</td> <td></td> <td>J-2102</td> </tr> <tr> <td>N</td> <td>D</td> <td>ALSTOM SIGNALING, INC.</td> <td></td> <td>441-5</td> </tr> </table>	QPL	CODE	MFG - NAME		MFG - PART-NO	---	---	-----		-----	N	P	ALSTOM SIGNALING, INC.		J-2102	N	D	ALSTOM SIGNALING, INC.		441-5					
QPL	CODE	MFG - NAME		MFG - PART-NO																							
---	---	-----		-----																							
N	P	ALSTOM SIGNALING, INC.		J-2102																							
N	D	ALSTOM SIGNALING, INC.		441-5																							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0293	03-14-5980	SCREW, 5/16-18, HEX HEAD, 1-1/4" FOR THROW BAR GUIDE, USED WITH #5 SWITCH MACHINE	EA	120	140	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 03440-045-00				
0294	03-14-6000	SCREW, 5/16-18 HEX HD 13/16 DOG PT W/WASH FOR 5 SW MACH CLUTCH	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 45554				
0295	03-14-6300	SCREW, 5/16" - 24 HEX. HEAD, 1" F PC YOKE UW 5 SW MACH.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 03440-080-00				
		N P ALSTOM SIGNALING, INC. PL J2116 FIG 37				
0296	03-14-6450	SCREW, 3/8"-16, 1", HEX. HEAD, W/WASHER #01273-8, FOR PLATE OF 7B SWITCH CIRCUIT CONTROLLER,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. K0136 FIG.10				
		N D ALSTOM SIGNALING, INC. 6170-2				
0297	03-14-6470	SCREW, 3/8-16 X 1-3/8 IN. HEX. HD. WITH LOCK WASHER, FOR FASTENING POLE CHANGER TO FRAME PLATE	EA	40	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 45617-001-00				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0298	03-14-6690	SCREW, 3F8-16 SET HEADLESS, 5F8 F/ PC. CORES UW 5 SW. MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 31399-000-00							
		N P ALSTOM SIGNALING, INC. PL J2116 FIG 33							
0299	03-14-6790	SCREW, 50576, 3/8 IN X 1/2 IN HEX. HD FOR ARM FIG. H,	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 50576-000-00							
		N P ALSTOM SIGNALING, INC. J-210 FIG.27							
0300	03-14-6900	SCREW, CAP, 7/16"-14, HEX HEAD, WITH WASHER #01273-9, FOR CLUTCH FRAME USED WITH #5 SWITCH MACHINE	EA		10		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 146-900							
0301	03-14-7155	SCREW, 5/8 IN. - 11, HEX HEAD, 2-1/4 IN., W/WASHER NO. 01273-11, FOR CLUTCH FRAME ON MODEL 5 SWITCH MACHINE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 02890-006-00							
0302	03-14-7355	SCREW, 3/4-10, HEX HEAD, 2-1/4", WITH WASHER NO. 01273-013-ON, FOR GEAR FRAME ON MODEL 5 SWITCH MACHINE	EA		24		10		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 147-355							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0303	03-14-7890	SHAFT F MAIN AND BEVEL GEAR U/W 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45545							
0304	03-14-7910	SHAFT, F FRICTION CLUTCH U/W 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 45560-000-00							
0305	03-14-8100	SHAFT, U/W SW CIR CONTLLR 7B 4 WAY ROUND HOBBED F CAMS	EA		00		24		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 38651-003-00							
0306	03-14-8115	SHAFT, U/W SWITCH CIRCUIT CONTROLLER 7B 6 WAY ROUND HOBBED, F 4 CAMS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 38651-9							
0307	03-14-8325	SHIELD, WITH NUT 1156-2, SCREW 14071-1, WASHER NO. 01273-8	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 39997-3							
0308	03-14-8650	SLEEVE, FOR MOTOR SHAFT U/W 5 SW MACH	EA		06		20		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 585-70							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0309	03-14-8800	SPACER, FOR M-5 SWITCH DETENT BRAKE	EA		10		10		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 38165-071-00							
0310	03-14-8970	SPRING, FOR BALL, FOR PIN OF STICK LOCK U/W 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 786-86							
0311	03-14-9050	SPRING, BRUSHHOLDER, U/W 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 01581-000-00							
0312	03-14-9140	SPRING, FOR HASP OF BRAKE COVER U/W 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 16771-42							
0313	03-14-9160	SPRING, FOR FRICTION CLUTCH U/W 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45553							
0314	03-14-9265	SPRING, CONTACT FOR BRAKE U/W 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 49909-2							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0315	03-14-9840	STAPLE, ONLY F/7B SW CIR CONTLLR.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 16914-016-00							
0316	03-15-0700	STUD, F/ COVER UW 7B SW CIR CONTLLR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 441-631							
0317	03-15-0705	STUD, F/ COVER UW 7B SW CR CONTLLR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 441-632							
0318	03-15-0730	STUD, F/HINGE LUG OF MOTOR UW. MOD. S SW MACH.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 441-236							
0319	03-15-0750	STUD, 5/8-11 HOLDS MOTOR TO 5 SW MACH	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 00980-019-00							
0320	03-15-0755	STUD, 1/2 IN. - 13, FOR FASTENING ADAPTER TO BASE,	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 00980-020-00							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0321	03-15-0815	STUD, F/LOCK RODS USED WITH 5 SW. MACH.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	47509		
0322	03-15-0835	STUD, F/ MAIN GEAR U/W 5 SW MACH	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	45542-004-00		
0323	03-15-1225	SUPPORT, FOR TERMINAL BLOCK, FOR SW. MACH. POLE CHANGER	EA	20	50	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	49591-000-00		
0324	03-15-1445	TUBE, FIBRE, ONLY FOR COIL FIG. 12, FOR POLE CHANGER, J-2116, FIG. 59	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	43131-004-00		
0325	03-15-1465	TUBE, FOR PLUNGER, MACH	EA	10	20	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	45574-001-00		
0326	03-15-1665	VENTILATOR, F/ CASE OF 7B SW CC AND SW MOTOR	EA	10	10	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	52981-003-00		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0327	03-15-1895	WASHER, INSULATING, FOR COILS, FIG. NO. 35, GENERAL RAILWAY SIGNAL	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	493-35		
0328	03-15-2065	WASHER	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	1601-87		
0329	03-15-2380	WASHER, SHIM, FOR ADJUSTMENT OF ARM U/W 5 SW MACH STAINLESS STEEL	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	05046-008-00		
0330	03-15-3225	YOKE, W/ PIN #500 F/ OPER ARM OF PC W/ FASTELL CONTACTS U/W 5 SW MACH	EA	10	19	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	56501-012-01		
0331	03-17-0700	BASE, COMP. F/AT BUMPER POST, SIG.,	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	43951-003-02		
0332	03-17-2000	BRACKET	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	35656-005-00		
	N	D	ALSTOM SIGNALING, INC.	PL.H3301, FIG 6		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0333	03-17-3380	CLIP, F/LENS W/ SCR #2438-12, WASH #53029-18 U/W AW FA SIGS.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 18547-48							
0334	03-17-3650	CONTACTOR, COMP F/ STOP REL U/W SIG LAYOUT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 04987-004-01							
0335	03-17-4015	DISC	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 39719-12							
0336	03-17-4280	DOOR, COMP FOR IND FA SIGNAL SWITCH UNIT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 15076-29 GR1							
0337	03-17-4302	DOOR, COMPLETE, FOR SIGNAL HEAD	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 15076-24-GR1							
0338	03-17-5345	GLASS, OPALESCENT U/W AT GRADE TIME SIG	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 924-20							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0339	03-17-5380	GLASS, F/ LETTERS U/W AT GRADE TIME SIG	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	50538-62		
0340	03-17-5610	GUARD, COMP F/ PB U/W AN SIG	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	54271GR1		
0341	03-17-5810	HANDLE, ONLY F DOOR OF AT SIG UNIT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	53717-2GR1		
0342	03-17-6015	HASP, TONGUE LOCKS COV TO CASE U/W AN AWSIG	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	36023-1		
0343	03-17-6215	HINGE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	43461-2		
0344	03-17-6255	HINGE, W/RIVET #224,	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	53666		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0345	03-17-6455	HOOD	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 35886-6							
0346	03-17-7385	LENS, 3 5/8 DIA 5/8 FOCUS INNER DOUBLET GREEN U/W AN-F SIGS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. **** PART NO. NOT AVAILABLE ****							
		N D ALSTOM SIGNALING, INC. 45926-1							
0347	03-17-7390	LENS, 3 5/8 DIA 5/8 FOCUS INNER DOUBLET YELLOW U/W AN-F SIGS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45926-2							
		N D ALSTOM SIGNALING, INC. 45926-15							
0348	03-17-7415	LENS, 3 5/8 DIA. 5/8 FOCUS INNER DOUBLET E. LUNAR WHITE UW AN F SIGS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45926-016-00							
0349	03-17-7660	LENS, 5" DIA 3 IF2 FOCUS OPTICAL GREEN UW A-AT SIGS, INTERIOR RIBBING	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 31624-008-00							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0350	03-17-7850	LENS, 5 1/2 DIA 1/2 FOCUS INNER DOUBLET LUNAR WHITE F/ TYPE AW SIGNAL	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	43988-029-00		
0351	03-17-8040	LENS, PLASTIC, HIGH IMPACT, RESISTANCE TYPE, 5" DIA., 3-1/2" FOCUS, CLEAR,	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	31624-041-00		
	Y	P	ALSTOM SIGNALING, INC.	64-3-C-GD		
0352	03-17-8041	LENS, PLASTIC, HIGH IMPACT, RESISTANCE TYPE, 5" DIA., 3-1/2" FOCUS, LUNAR WHITE, USED WITH A-AT SIGNAL	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	64-3-LW-6D		
0353	03-17-8045	LENS, PLASTIC, HIGH IMPACT, RESISTANCE TYPE, 5-1/2" DIA, 1/2" FOCUS, GREEN, INNER DOUBLE TYPE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	43988-025-00		
	Y	P	ALSTOM SIGNALING, INC.	P73-948		
0354	03-17-8050	LENS, PLASTIC, HIGH IMPACT, RESISTANCE TYPE, 5-1/2" DIA. 1/2" FOCUS, YELLOW, INNER DOUBLE T TYPE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	6690		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0355	03-17-8055	LENS, PLASTIC, HIGH IMPACT, RESISTANCE TYPE 5-1/2" DIA., 1/2" FOCUS, RED, INNER DOUBLE T TYPE	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC.				6690
0356	03-17-8056	LENS, PLASTIC, HIGH IMPACT, RESISTANCE TYPE 5-3/8- #DIA., 3-1/2" FOCUS GREEN OPTICAL TYPE,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC.				64-3GG
0357	03-17-8057	LENS, PLASTIC, HIGH IMPACT, RESISTANCE TYPE 5-3/8- #DIA., 3-1/2" FOCUS YELLOW, OPTICAL TYPE,	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC.				64-3
0358	03-17-8058	LENS, 5-3/8" DIA., 3-1/2" FOCUS, RED, PLASTIC	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC.				64-3 R
0359	03-17-8060	LENS, PLASTIC, HIGH IMPACT, RESISTANCE TYPE, 6-3/8" DIA., 3-3/4" FOCUS, CLEAR	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC.				6560C-L

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0360	03-17-8070	LENS, PLASTIC, HIGH IMPACT, RESISTANCE TYPE, 8-3/8" DIA. X 4" FOCUS CLEAR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 6450							
0361	03-17-9355	PLUNGER, FOR PUSH BUTTON USED WITH AN SIGNAL	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. PL.H.2512 FIG. 35							
		N D ALSTOM SIGNALING, INC. 48108-1							
0362	03-17-9765	POST	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. PL.H.2508							
		N D ALSTOM SIGNALING, INC. 52908-2							
0363	03-17-9770	POST	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. PL-H2508 FIG. 9							
		N D ALSTOM SIGNALING, INC. 52908-1							
0364	03-18-0050	RECEPTACLE, LAMP ONLY S-C-CAND-BAY BASE F AW-FA-ME-SIG	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 34864-013-00							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0365	03-18-0070	RECEPTACLE, LAMP. COMP 3 PIN U/W AN SIG	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	49102-8GR1		
0366	03-18-0125	RECEPTACLE, LAMP COMP F/ NUMBER PLATE U/W AT SIG	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	53058-7GR1		
0367	03-18-0130	RECEPTACLE, LAMP, COMP S-C-C &-BAY BASE, U/W AT SIG.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	53058-8GR1		
0368	03-18-0150	RECEPTACLE, LAMP, COMP. F-AW-FA-ME-SIG.S. C. BAY BASE,	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	53058-25-GR1		
0369	03-18-0155	RECEPTACLE, LAMP, COMP F NUMBER PLATE, UW AW SIG	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	53058-26, GR. 1		
0370	03-18-0160	RECEPTACLE, LAMP, COMP. U/W 1 IND. AT SIG	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	53058-27-GR. 1		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0371	03-18-0380	RING	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	PL-H3305 FIG 19					
	N	D	ALSTOM SIGNALING, INC.	43432-7					
0372	03-18-0405	RING	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	PL-H-2512 FIG. 37					
	N	D	ALSTOM SIGNALING, INC.	43983-6					
0373	03-18-0415	RING, BEZEL FOR AT GRADE TIME, SIG	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	PL-H-3305 FIG. 49					
	N	D	ALSTOM SIGNALING, INC.	43983-18					
0374	03-18-0455	RING, FOR LENS AT INDOOR SIGNAL	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	43983-55					
0375	03-18-0465	RING, BAZEL, BLANK, FOR INDOR AT SIGNAL.	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	43983-121					

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION		U/M	USE	PY2	USE	PY1	USE	YTD
0376	03-18-0760	ROUNDEL		EA		00		00		00
		QPL	CODE	MFG - NAME		MFG - PART-NO				
		N	P	ALSTOM SIGNALING, INC.		9234-16				
0377	03-18-0765	ROUNDEL		EA		00		00		00
		QPL	CODE	MFG - NAME		MFG - PART-NO				
		N	P	ALSTOM SIGNALING, INC.		9234-17				
0378	03-18-0850	ROUNDEL		EA		00		00		00
		QPL	CODE	MFG - NAME		MFG - PART-NO				
		N	P	ALSTOM SIGNALING, INC.		9238-86				
0379	03-18-1525	SCREW		EA		00		00		00
		QPL	CODE	MFG - NAME		MFG - PART-NO				
		N	P	ALSTOM SIGNALING, INC.		PL.H.3305 FIG. 43				
		N	D	ALSTOM SIGNALING, INC.		2438-1				
0380	03-18-3300	SIGNAL, COMPLETE, AUTOMATIC, THREE ASPECT, SUBWAY A.T. TYPE		EA		00		00		00
		QPL	CODE	MFG - NAME		MFG - PART-NO				
		N	P	ALSTOM SIGNALING, INC.		36722-266-GR2				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0381	03-18-3303	SIGNAL, "AT" SUBWAY WALL MOUNTED ASPECT-AT200-001-03 COMPLETED WITH SIGNALING LATEST DWG #AT100-00-00 REV A.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO Y P ALSTOM SIGNALING, INC. AT100-009-01				
0382	03-18-3308	SIGNAL, HOME CMPLT W/S UNIT SBWY TYPE GRS	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO N P ALSTOM SIGNALING, INC. 36722-266-GR8				
0383	03-18-4200	SOCKET, F/MOUNTING AN - AW SIGS TO 3" PIPE	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO N P ALSTOM SIGNALING, INC. 28447-66				
0384	03-18-4205	SOCKET, FOR MOUNTING A.T. SIGNAL TO 3" PIPE.	EA	12	00	00
		QPL CODE MFG - NAME MFG - PART-NO N P ALSTOM SIGNALING, INC. 28447-011-00				
0385	03-18-5070	STUD, USED AS HINGE PIN ON AT SIG.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO N P ALSTOM SIGNALING, INC. 441-483				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0386	03-18-5469	UNIT, LENS, RED FOR AN SIGNAL	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 36762-19-GR16				
0387	03-18-5480	UNIT, SIGNAL, LUNAR WHITE, W/HOOD #49127-9	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 36722-279-GR1				
0388	03-18-5490	UNIT, LENS, COMP GREEN U/W AW OUTDOOR SIG	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 36762-33GR1				
0389	03-18-5491	UNIT, LENS, COMP YELLOW U/W AW FA	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 36762-33GR2				
0390	03-18-5492	UNIT, LENS, COMP RED U/W AW OUTDOOR SIG	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 36762-33GR3				
0391	03-18-6200	UNIT, SIGNAL, CALL-ON, COMPL., OUTDOOR	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 36722-279-01				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0392	03-18-6500	UNIT, SIG., AT COMP. 1 IND LETTER S INDOOR	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	36722-160-GR1		
0393	03-18-7405	UNIT, SIGNAL, COMPLETE, SIGNAL TYPE, AW WITH G, Y, R & G, Y, R ASPECTS WITH CALL-ON UNIT AND A YELLOW ASPECT, WITH POLE & PEDESTAL AS INSTALLED ON CONTRACT S-104 BROADWAY LINE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	45906-341 GR-3		
0394	03-21-0310	ARM, F OPERATING ARM U/W STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48627		
0395	03-21-0395	ARM, ADJUSTING, COMPLETE WITH ROLLER BREAKERS ON IMPEDANCE TYPE TRAIN STOPS FOR OPERATION OF CAM TYPE, STOP CIRCUIT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	53980-007-02		
0396	03-21-0455	ARM, TRIPPER, COMPLETE FOR ROCKER SHAFT, USED WITH STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	48626-003-01		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0397	03-21-0460	TRIPPER ARM, COMP., F ROCKER SHAFT UW STOP.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	48626-004-01		
0398	03-21-0465	ARM, TRIPPER, COMPLETE, FOR ROCKER SHAFT, USED WITH STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48626-006-01		
0399	03-21-0485	ARM, TRIPPER COMP. FOR ROCKER SHAFT U/W STOP FOR RH TRIPPING	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48626-8-GR1		
0400	03-21-0490	ARM, TRIPPER, COMPLETE, LEFT HAND, CAP STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	48626-010-01		
0401	03-21-1064	BEARING, ONLY FOR ROCKER SHAFT U/W STOP LAYOUT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48629-005-00		
0402	03-21-1070	BEARING, ONLY FOR ROCKER SHAFT, USED WITH STOP LAYOUT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48629-009-00		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0403	03-21-1095	BEARING, ONLY FOR ROCKER SHAFT, USED WITH STOP LAYOUT, FOR BEARING A WITH FITTING "34232-17"	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 54181-001-01							
0404	03-21-1110	BEARING, ONLY FOR ROCKER SHAFT, FOR ALEMITE FITTING, USED WITH STOP LAYOUT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 54181-000-02							
0405	03-21-1200	BEARING, COMP. WITH PLATE DRAWING NO. 40627-78, BEARING, COMP. DWG. #29790-4 NUT-1"-12 HEX X 1/2" THICK DWG.#50164-1 & WASHER-1" DWG.#01273-15 FOR ROCKER SHAFT BEARING U/W TRAIN STOP LAYOUT DWG.#48637KN	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 48628-051-01							
0406	03-21-1370	BEARING, FOR ROCKER SHAFT COMP. WITH STRAP U/W STOP LAYOUT WITH FITTING 34232-41-GR2	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 48628-30-GR1							
0407	03-21-1378	BEARING, COMPLETE, WITH STRAP CAP STOP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 48628-051-05							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0408	03-21-1386	BEARING, COMP. WITH FITTING 34232-41-1 U/W STOP LAYOUT (FOR TYPE & ROADBED)	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 48628-33-GR2							
0409	03-21-1590	BLOCK, TERMINAL, ONLY FOR MOTOR UW STOP.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 43130							
0410	03-21-2430	BOLT, 3/8"-24 X 1-3/16", FOR STOP TRIPPER ARMS	EA		00		60		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 02889-009-00							
0411	03-21-2940	BOLT, 5F8-11 SQ. HD. 2-3/4 W/NUT, F ROD USED WITH STOP LAYOUT.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. PL L 3011 FIG 6							
		N D ALSTOM SIGNALING, INC. 41927-1							
0412	03-21-3190	BOLT, 3/4-10 HEX HD 2-3/4 WITH NUT #4364-2 & WASH FOR STOP TRIPPER ARM	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 069-1070-0-0							
		N D ALSTOM SIGNALING, INC. 34319-1							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0413	03-21-4320	BUSHING, INSULATION FOR STOP ROD BOLT	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 7350-65				
0414	03-21-4380	BUSHING, FOR NUT OF STOP HOLD CLEAR MAGNET	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 43153-000-00				
0415	03-21-4880	CAP, FOR STOP SHAFT	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 48622				
0416	03-21-5380	CASE, ONLY F/STOP 15/16 HOLES	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 50110-12				
0417	03-21-6000	COIL, ELECTRICAL, ONLY FOR 60 HV., 110V STOP MAGNET.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 43125-000-01				
0418	03-21-6010	COIL, ONLY FOR 25 CY. 110-V. STOP MAGNET	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 43125-GR2				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0419	03-21-6235	COLLAR, FOR END OF ROTOR SHAFT U/W STOP MOTOR	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	30650-1		
0420	03-21-6885	CONNECTOR, COPPER F, STOP HOLD CLEAR POST	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	42760-181-04		
0421	03-21-7080	KIT, CONTACT WITH NUT, FOR #42839-8 CONTACT P/N #42799-016-01 AND NUT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	217-080		
0422	03-21-7170	CONTACT, ONLY F STOP HOLD CLEAR ARM.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	54683-006-00		
0423	03-21-8180	CRANK, COMPENSATING F/ STAND U/W STOP LAYOUT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	743-15		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0424	03-21-8200	CRANK, COMP F/ ROCKER SHAFT U/W STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	48624-000-01		
0425	03-21-8205	CRANK, COMP F/ ROCKER SHAFT U/M STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48624-001-01		
0426	03-21-8215	CRANK, F/ ROCKER SHAFT U/W STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48624-2GR1		
0427	03-21-8640	DISC, F/ STOP MOTOR	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	43128-3		
0428	03-21-9060	DRIVER, COMPLETE, FOR ROCKER SHAFT, USED WITH STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	48625-001-01		
0429	03-21-9070	DRIVER, COMP F/ ROCKER SHAFT U/W STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48625-3GR1		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0430	03-21-9080	DRIVER, COMP F-RH SIDE OF STOP ROCKER SHAFT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48625-4GR1		
0431	03-22-0200	GASKET, F BLOCK HOLD CLEAR ASSY, U/W STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	13014-156		
0432	03-22-1320	HOOK, FOR STOP TRIPPER ARM	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	51049-2		
0433	03-22-1360	HOOK, COMP F/ TRIPPER ARM GRS U/W STOP LAYOUT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	54185-2GR1		
0434	03-22-1365	HOOK, STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	54185-2GR4		
0435	03-22-1375	HOOK, COMP F/ TRIPPER ARM F/ HOLDING DOWN TRIPPER ARM U/W STOP LAYOUT GRS	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	54185-7-GR1		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0436	03-22-1400	HOOK, COMPLETE, RIGHT HAND (R/H) FOR CAPACITOR TRAIN STOP	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 54185-013-01				
0437	03-22-1401	HOOK, COMPLETE R.H. F/CAPACITOR TRAIN STOP	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 54185-013-02				
0438	03-22-1402	HOOK, LEFT HAND, FOR CAPACITOR TRAIN STOP	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 54185-010-02				
0439	03-22-1403	HOOK, L.H. CAP STOP	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 54185-010-01				
0440	03-22-1410	HOOK, LEFT HAND, CAP STOP	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 54185-015-01				
0441	03-22-2413	SHAFT ASSEMBLY, FOR CAPACITOR STOP ON SUPER ELEVATED LAYOUT	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 20664-2				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0442	03-22-2800	LAYOUT, ELECTRIC TRAIN STOP, R.H. TRIPPING, GRS CAPACITOR TYPE, 60 CYCLES, 110 VOLTS, FOR TYPE1 (ONE) SUBWAY TRACK CONSTRUCTION	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO N P ALSTOM SIGNALING, INC. 48637-84, GR1-GR2							
0443	03-22-2801	LAYOUT, AUTO TRAIN STOP, R H TRIPPING, TYPE 111, ELEVATED STRUCTURE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO N P ALSTOM SIGNALING, INC. 48637-85-GR1							
0444	03-22-2810	LAYOUT, R.H. AUTOMATIC TRAIN STOP U/W MECHANISM BETWEEN 60CYCLE, EXCEPTIONS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO N P ALSTOM SIGNALING, INC. 48637-84-GR1							
0445	03-22-2811	LAYOUT, STOP, LESS STOP, W/ SCREW 68, WASHER #72-2, SHIMS #304-136, WASHER #1273-7, SHIMS #41673-54, SHIMS #41673-55, PLATE #41885-119, COUPLING #45689-185, BOLT & NUT #48058-1, ARM #48262-10GR1 BRG #48628-43GR1, SHAFT #48630-52, SCREW #51580-1, HOOK #54185-10GR2, CON. 56353-9 LAYOUT, STOP, LESS STOP, W/ SCREW 68, WASHER #72-2, SHIMS #304-136, WASHER #1273-7, SHIMS #41673-54, SHIMS #41673-55, PLATE #41885-119, COUPLING #45689-185, BOLT & NUT #48058-1, ARM #48262-10GR1 BRG #48628-43GR1 , SHAFT #48630-52, SCREW #51580-1, HOOK #54185-10GR2, CON. 56353-9	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO Y P ALSTOM SIGNALING, INC. 222-811							
0446	03-22-2814	LAYOUT, ONLY F/ELECTRIC TRAIN STOP L.H. TRIPPING GRS CAPACITOR TYPE. FOR SPRING	EA		00		00		00

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
		MOUNTING BETWEEN RAILS, TYPE THREE (3) ELEVATED CONSTRUCTION. LESS TRAIN STOP MECHANISM.				
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 48637-107-GR-1				
0447	03-22-2815	LAYOUT, ELECTRIC TRAIN STOP, L.H. TRIP- PING, FOR GRS CAPACITOR TYPE STOP, SPRING MOUNTED BETWEEN RAILS TYPE THREE (3) ELEVATED CONSTRUCTION.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 48637-107-GR1				
0448	03-22-2816	LAYOUT, ELECTRIC TRAIN STOP COMPL. L.H. TRIPPING, CAPACITOR TYPE MOTOR, 110 V 60HZ, FOR TYPE 2 SUBWAY TYPE #50100-18GR1 CONSTRUCTION, W/ STOP MECHNISM COMPLETE	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 48637-75-GR1				
0449	03-22-2817	LAYOUT, COMPL., STOP L.H. CAPACITOR TYPE, 25 CYCLE, 110 VOLTS, FOR TYPE 2 TRACK SUBWAY CONSTRUCTION WITH MECHANISM #50100-18 GR 2	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 48637-72 GR 1				
0450	03-22-2819	LAYOUT, COMPLETE, FOR 60 HZ, CAPACITOR STOP, BENCH WALL TYPE, L.H. WITH STOP MECHANISM	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 50100-18 GR1				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0451	03-22-2820	LAYOUT, COMPLETE, CAPACITOR STOP, BENCH WALL TYPE, L.H. WITH STOP MECHANISM DWG.50L00-L8, GR. 1 FOR 60 HZ	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48687-105-01		
0452	03-22-2821	LAYOUT, TRAIN STOP COMPLETE CAPACITOR TYPE, BENCH WALL, MOUNTED R.H.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48637-96 GR-1		
0453	03-22-4500	NUT, 5/16-18HEX F/ CIRCUIT BREAKER ARM OF STOP	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	01155-016-00		
0454	03-22-6680	PINION STOP, FOR MOTOR ROTOR SHAFT, PLATE L-3017, FIG. 57, 50200-1	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	50200-1		
0455	03-22-6998	PLATE, PART OF ROCKER SHAFT BEARING COMPLETE, DWG 48628-51, GR-1 FOR TRAIN STOP LAYOUT #48637KN	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	48628-51 GR-1		
	N	D	ALSTOM SIGNALING, INC.	40627-78		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0456	03-22-7012	PLATE, SUPPORT FOR CAPACITOR STOP MECHANISM	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	41885-124		
0457	03-22-7200	PLUG, TRAIN STOP, CAPACITOR GEAR BOX, BRASS FILLER PLUG	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	31408-004-00		
0458	03-22-7435	POST COMP F/ HOLD CLEAR CONTACT ASSY W/ CONTACT U/W STOP MOTOR	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	48817 GR1		
0459	03-22-8250	ROD, F STOP LAYOUT, ONLY SOLID JAW TO INSUL 113F4	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	129-1		
0460	03-22-8270	ROD F STOP LAYOUT, ONLY 32 IN 10 IN THREAD	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	34075-12GR4		
0461	03-22-8310	ROD, F STOP LAYOUT ONLY 73 IN 9 IN THREAD	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	34075-12 GR20		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0472	03-23-2000	SHAFT, FOR STOP CIRCUIT BREAKER, UNDRILLED	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 50393-1							
0473	03-23-2295	SHAFT, ROCKER, F/TRIPPER ARM, U/W STOP LAYOUT 15 7F8 LG. REF. 4 OF DWG. 48637-38	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 48630-040-00							
0474	03-23-2296	SHAFT, ROCKER USED WITH GRS CAPACITOR TYPE TRAIN STOP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 48630-052-00							
0475	03-23-2400	SHIM, FOR BEARING STRAP U/W CAPACITOR TRAIN STOP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 41673-054-00							
0476	03-23-2410	SHIM, FOR STOP CASE CAP STOP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 304-135							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0477	03-23-2415	SHIM, BEARING COMPLETE, CAP S	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 304-136							
0478	03-23-2420	SHIM, CAP STOP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 304-149							
0479	03-23-3150	SPACER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 35462-9							
0480	03-23-3160	SPACER, FOR SPRING CAP STOP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 35462-16							
0481	03-23-3430	SPRING, FOR MOUNTING MECHANISM ON STRUCTURE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 00786-059-00							
0482	03-23-3460	SPRING, INNER WITH TWO EYELET 41858 U/W STOP MOTOR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 786-153							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0488	03-23-3985	STAND, COMPLETE, FOR CRANK U/W STOP LAYOUT WITH FITTING	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	8206-1-GR-5		
0489	03-23-4315	STOP, CAPACITOR, COMPL., 110V., 25 CYCLE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	50100-21-GR-2		
0490	03-23-4565	STUD, ONLY 1 FOR 4-24 FOR MAGNET STOP MOTOR	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	43147		
0491	03-23-4675	STUD, COMPLETE, CAP STOP.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	43106-012-01		
0492	03-23-5070	VENTILATOR, COMPLETE U/W STOP CASE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	52981-GR1		
0493	03-23-5340	WASHER, STAINLESS STEEL, LOCK 7F8 F/BOLTHOLDING STOP CASE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	01273-014		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0494	03-23-5440	WASHER, FOR LAG SCREW, WASHER LAG SCREW FOR MOUNTING MECHANISH TO TIES	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 626-72 PLATE L-3031, FIG.15							
0495	03-23-5446	WASHER, FOR SPRING CAP STOP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 00626-219-00							
0496	03-23-5450	WASHER	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 626-195							
0497	03-23-5460	WASHER, SPECIAL, F VIBRATION SPRING U/W STOP CASE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 4333-16							
0498	03-23-5465	WASHER, FOR SPRING MOUNTED STOP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 04333-022-00							
0499	03-23-5510	WASHER, FOR FIRST SHAFT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 30078-4							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0500	03-23-5515	WASHER. FOR ROTOR SHAFT PINION OF STOP MOTOR	EA		00		130		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 30078-005-00							
0501	03-26-1520	BASE, ONLY F-RLY. BOX	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 40522							
0502	03-26-1525	BASE, MOUNTING FOR RELAY CASE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 40522-5							
0503	03-26-1560	BASE, COMP. FOR MOUNTING RELAY BOX" NICHE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 48886-GR1							
0504	03-26-1575	BASE, COMP-F-RLY BOX, PL. E0961 FIG. H.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 48886-2-GR1							
0505	03-26-1810	BELL	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55342-1GR1							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0506	03-26-2355	BLOCK, FUSE GRS U/W RELY BOX COMPLETE FOR 8-0-30A 600 VOLTS FUSES AND 12 TERMS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 26665-16 GR1							
0507	03-26-3395	BOARD, TERM COMPLETE WITH 20 TERM BLKS U/W JCT BOX	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. **** PART NO. NOT AVAILABLE ****							
		N D ALSTOM SIGNALING, INC. 45857							
0508	03-26-6240	BOX, JUNCTION, COMPLETE, 1, PL. N-1903, FIG. A, FOR POWER MAIN TAPS AT RELAY BOX	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 54678 GR1							
0509	03-26-6320	BOX, JUNCTION COMPLETE WITH 36 POST DOOR STOP VERT MTG 2 1/2 OPENING AT BOTTOM	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 54679-14 GR1							
0510	03-26-6365	BOX, JUNCTION WITH 2 TERM-1-0-30A FUSE BLACK	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 54679-22 GR1							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0517	03-27-0480	COVER, TOP F RLY BOX	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 47819				
0518	03-27-0485	COVER, ONLY TOP RLY BOX FOR 3-2" 2-2-1/2	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 47819-4				
0519	03-27-0500	COVER, ONLY TOP RLY BOX BLANK	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 47819-8				
0520	03-27-0520	COVER, FOR RELAY BOX BASE	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 48308				
0521	03-27-0900	DOOR, F/RLY. BOX COMP. W/VENT, LATCH, GAS KET, HINGES, GRS DWG. 37868-26GR1 PL. E0 965 FIG. 4	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 37868-26GR1				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0522	03-27-2270	HINGE, ONLY FOR RLY BOX DOOR	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 53666-3							
0523	03-27-2580	INSULATOR, FOR PLUGBOARD.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55862-8							
0524	03-27-2600	WRENCH, E POST FOR TYPE "B" RELAY TEST TERMINAL NUT	EA		00		36		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55393-003-01							
0525	03-27-2690	KIT, PLUG BOARD, COMPLETE WITH TERMINAL CLIPS AND INSULATORS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. A62-0506							
0526	03-27-3505	MOUNTING, RELAY, COMPLETE FOR B1 BIASED NEUTRAL LINE RELAY 56001-785 GR26	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 30268-GR1 SPL.							
0527	03-27-3575	MOUNTING, RELAY, COMPLETE, FOR TYPE B SIZE 2 TIME RELAY 50GR1-51GR1-60GR1-61 GR1	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 30268-1							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0528	03-27-3585	MOUNTING, RELAY COMP FOR B2V 60 C4 TK RLY 56005 100 GR1	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 30268-1 GR2				
0529	03-27-6830	PLATE, F JCT BOX TAPPED F-3-2 IN CONDUIT	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 44512-6				
0530	03-27-7195	PLATE, REGISTRATION FOR B2V TRACK RELAY	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 58876-1GR10				
0531	03-27-8300	PLUG, BOARD, ONLY, FOR "J" RELAY	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 01099-000-ON				
0532	03-27-8728	PLUG BOARD, WITH INSULATORS AND PLASTIC CLIPS F B2 RLY	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 59686-1 GR1				
0533	03-27-8755	PLUG BOARD, F B1 RLYS ON RACK	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 59686-005-01				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0534	03-27-9250	POST, TEST COMPLETE 3E POST ON GRS PLUGBOARD FOR GRS RELAY	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	42788-001-01					
	N	D	ALSTOM SIGNALING, INC.	42788GR1 REF. 8 59					
	N	D	ALSTOM SIGNALING, INC.	686-1					
0535	03-27-9255	POST, TEST TERMINAL ON GRS PLUGBOARD FOR GRS RELAY	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	42788-001-02					
	N	D	ALSTOM SIGNALING, INC.	42788GR2 REF. 8 OF					
	N	D	ALSTOM SIGNALING, INC.	59686					
0536	03-28-0060	LENS ASSEMBLY, W/GASKET, PILOT LIGHT PUSH BUTTON BOX DWG 33933-25, USED WITH TRAIN IDENTITY	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	33933-030-00					
0537	03-28-0065	LIGHT, PILOT, COMPLETE F PUSH BUTTON, USED WITH TRAIN IDENTITY PUSH BUTTON BOX	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	33933-025-00					
0538	03-28-5760	SWITCH, D.P. 1. 1 AMP, THERMAL FOR A.C. GROUND DETECTOR SYSTEM -15, REF 267 ON T.A.	EA		00		00		00
	QPL	CODE	MFG - NAME	MFG - PART-NO					
	N	P	ALSTOM SIGNALING, INC.	54673-015-00					

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0539	03-28-5780	SWITCH, DPDT 3 POS TYPE MCM AAAA, F NX TEST BD	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	56970 -4		
0540	03-28-7200	POWER SUPPLY UNIT, 15 VOLT, 60 CYCLE ADJ. 10-15V. - 2.5A, 35100 V. - 0.3A FOR INDISCAN	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	59761-47 GR1 REF 1		
0541	03-31-0250	BRACKET, F MESSINGER WIRE, ONLY VERT WALL MTG 4 IN OFFSET	EA	50	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	54899-000-00		
	N	D	ALSTOM SIGNALING, INC.	FIG. 7		
0542	03-31-4300	CONDENSER, 70 MFD F TRACK CIRCUITS	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	47630-29-G1		
0543	03-31-4820	IMPEDANCE, BALANCING, USED WITH 2A TK RELAY.	EA	10	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	42960-001-01		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0544	03-31-6200	BOND, REACTOR, IMPEDANCE, COMPL. 750 500,000 C.M.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45980-004-01							
0545	03-31-6635	BOND, REACTOR, TERMINAL FOR TK WIRES	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. R-20032							
0546	03-31-7095	RECTIFIER, 25 CYCLES, SQ. 1/2, 110 VOLT SAC, 12 VOLTS DC., .2A SELINIUM	EA		10		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 59847-002-10							
0547	03-31-7440	RECTIFIER, 300 PIV 75 MA	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 4008GR1							
0548	03-31-7450	RECTIFIER, 60 LY, 300 PIV-100 REV-75 VDC, GR2 DIODE TYPE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 400-8, GR2							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD	
0549	03-31-7500	RECTIFIER, SQ 1/2, 110 V, 60HZ, 12 V.D.C20 AMP.	EA	20	00	00	
	QPL	CODE	MFG - NAME	MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.	59847-002-04			
0550	03-31-7505	RECTIFIER, SELINIUM, COMPLETE, TYPE DETECTOR JACKS, FOR 12 VOLT LOCAL 12 VOLTS, 0.200 AMPS. AC INPUT 110	SQG1/2 WITH INSULATED NUTS AND GROUND CIRCUITS, RATING AS FOLLOWS: DC OUTPUT VOLTS, 50/100 CYCLES	EA	20	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.	59847-003-02			
0551	03-31-7510	RECTIFIER, COMPLETE, TYPE SQG1/2, IN	110 VAC, 24 VDC OUTPUT.	EA	30	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.	59847-003-05			
0552	03-31-7520	RECTIFIER, 60 CY., B3P 224, 115 V-AC 12 V-DC, 6A, FOR 12 VOLT SUPPLY	EA	00	00	00	
	QPL	CODE	MFG - NAME	MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.	59894-2 GR2			
0553	03-31-7580	RECTIFIER, 60 CYCLE, 4-BQ-1/4; 32V.DC.	EA	00	00	00	
	QPL	CODE	MFG - NAME	MFG - PART-NO			
	N	P	ALSTOM SIGNALING, INC.	58580-2, GR1, REF48			

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0554	03-31-7599	RECTIFIER, 60 CY, 55 VAC-10-50 VDC.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	59899-4, GR1		
0555	03-31-7800	RECTIFIER, SQ., 1/2 INPUT 2 VAC, .59847-2-GR7.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	59847-2 GR7		
0556	03-31-8719	RESISTOR, BLACK, WITH GLOBAR A, 30000 OHM RES, FOR POWER OFF INDICATOR	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	26665-019-01		
0557	03-31-8780	RESISTOR, 3 OHMS, 20 WATTS	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	01246-1		
0558	03-31-8782	RESISTOR, 5 OHMS, 77 WATTS	EA	100	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	56105-012-00		
0559	03-31-8830	RESISTOR, 600 OHM COMPLETE WITH BRACK UW WP RLY	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	43286-2 GR-1		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0560	03-31-8873	RESISTOR, 2- 70 OHM 26W MTG ASSY FOR POWER DIST	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45456-12-GR3							
0561	03-31-8950	RESISTOR, 111 OHMS, 15 WATT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 46450-22-GR9							
0562	03-31-8955	RESISTOR, COMP 0.017 TO 0.7 OHM W/SLIDE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 46450-023-02							
0563	03-31-8975	RESISTOR, CONSISTING OF RESISTOR 53587-10, BLOCK NO. 5971-22, WASHER NO. 1225-2, BOLTS NO. 42839-5 NO. 56482	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 50482-22 GR1							
0564	03-31-9015	RESISTOR, UNIT 8-510 OHM A-CAB MTG SNUB	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 51459GR1							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0565	03-31-9045	RESISTOR, 10 OHMS, 10 WATT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 53587-3							
0566	03-31-9054	RESISTOR, 25 OHM CUR LMTG F-A-CAB MTG	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 53587-4							
0567	03-31-9055	RESISTOR, 70 OHMS, 26 WATT	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 58869-2							
0568	03-31-9060	RESISTOR, ONLY 100 OHM 10W CUR LMTG	EA		12		12		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 53587-10							
0569	03-31-9100	RESISTOR, COMPLETE, 6 OHMS, TAPS 3-2-1, FOR YARD TRACK CIRCUITS	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55293-9							
0570	03-31-9120	RESISTOR, W#/MOUNTING, 30 OHM. 126 W, 3-10 OHM RESISTOR, FOR A.C. GROUND DETECTOR SYSTEM	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 56951-7							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0571	03-31-9130	RESISTOR, ONLY 30000 OHM FOR 3 RAIL IND	EA	00	36	18
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	55593-000-00		
0572	03-31-9205	RESISTOR, 1.5 OHM, 133 WATT FOR TRACK CIRCUIT	EA	100	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	Y	P	ALSTOM SIGNALING, INC.	56951-008-00		
0573	03-31-9208	RESISTOR, 70HM 77 WATT F/TRACK CIRCUITS	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	56105-7		
0574	03-31-9209	RESISTOR, 2.5 OHM, 77 WATT FOR TRACK CIRCUIT	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	56105-8		
0575	03-31-9210	RESISTOR, 68 OHM 2W W MTG ASSY UW 135V-DC -GRD DET. RLY	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	57831-14-GR1		
0576	03-31-9225	RESISTOR, 2000 OHM 2W-W-MTG ASSY F CAIB- SNUBBING RLYS	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	59273-1		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0577	03-31-9240	RESISTOR, 1500 OHM 2W-W MTG ASSY FOR CALB 24V GRD DET	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 57831-19 GR1							
0578	03-31-9266	RESISTOR, 1500 OHM-19W-UW-135V-GRD DET	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 5878-4 REF 85							
0579	03-31-9295	RESISTOR, 510 OHMS 2W-SNUB F/135V GRADE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 59723-7 REF 84							
0580	03-31-9500	TERMINAL, USED WITH REACTOR BOND, F/384,000 CIR. MIL CABLE, SIMILAR TO FIG. 7B-	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 45997-1							
0581	03-31-9510	TERMINAL USED WITH REACTOR BOND, F/ 384000 CIR MIL CABLE SIMILAR TO FIG 9B, EXCEPT FOR 384000 CIR MIL CABLE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. PL. R-0301							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0582	03-32-2300	BASE, SPLIT, 2" COMPLETE FOR TIME SIGN	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 30408-1-GR1							
0583	03-32-3505	SIGN, ILLUMINATED TIME, COMPLETE FOR 2 INCH POLE MTG WITH RUBBER RECPT WO POLE BASE LAMP	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 46400-5 GR1							
0584	03-32-3530	SIGN, ILLUM TIME COMPLETE WITH PORCELAIN RECPT BRACKET WITH 2 1F2" HOLE CENTERS WO LAMP AND PLATE	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 46400-3-GR2							
0585	03-32-6780	WRENCH, SOCKET, 1/2" HEX, FOR TERMINAL POST NUT	EA		178		00		40
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 15194-010-02							
0586	03-32-6920	WRENCH, 3/8-1/2, WITH OFFSET 3" LONG, FOR TERM POST AND GUIDE RODS.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 43576-030-00							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0587	03-32-7520	BOX, JUNCTION, COMP 1 SIDE PL F-IN OTHER	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 56773				
0588	03-32-7740	BOX, RISER COMP. F/TK CONN W/3" COND. OPENINGS	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 56768				
0589	03-33-0631	TRANSFORMER, 25 CY GRS TYPE K1 REPAIR	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 38270 GRS-3				
0590	03-33-0715	TRANSFORMER, 25 CYCLE, 145 KVA, 110V PR1 2 SEC 110V 55-55 14V-TAP-4-3-5, 1-7-F, LGTST K-CIR	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 38270-100-05				
0591	03-33-0722	TRANSFORMER, K 1/2, 60 CYC. PRI. 115 V SEC 19.5V .025 KVA, POWER BOARD ON RACK	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 38270-21GR9 REF259				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0592	03-33-0900	TRANSFORMER, TYPE K, SIZE 2, GR. 2, 3-1-2-2-1-3, AND 1-14, 41 AMPS., 2 PRIMARY 015-5-5, 600 VOLT	EA	00	00	00
		TRACK SECONDARY 14V, TAPPED SECONDARY 55 AND 60, 0.3 AMP. TE.,				
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 38270-22 GR2				
0593	03-33-4210	TRANSFORMER 60 CY .D10 KVA-110V -PRI-110V- SE F/PO IND RLY	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 53715 GR6				
0594	03-33-4220	TRANSFORMER, 60 CYCLES, TYPE S1, .020 WITH WP RELAY	EA	00	20	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 53715-105-01				
0595	03-33-4400	TRANSFORMER, S-I, .060 KVA, 60 CYCLE OUTDOOR	EA	00	00	00
		FOR SIG. HEADS OUTDOOR SIG. HEADS				
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 53715-143-01				
0596	03-33-4401	TRANSFORMER, S-2, 60 CYCLE, FOR SIGNAL HEAD INDOORS	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 53715-144 GR1				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0597	03-33-4520	TRANSFORMER 60 CY GRS TYPE S2 .002 KVA-110V-PRI- 4.5V, S2AS36	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 53715-2 GR1				
0598	03-33-4560	TRANSFORMER, 60CY GRS TYPE S2, CUR-F-OS-TK CIR.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 53715-7GR1				
0599	03-33-4820	TRANSFORMER, 60 CY GRS TYPE-T-, .080 KVA, 110 V.- PR1-8V-SEC F/AC GRD DET.	EA	06	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 59700-000-1				
0600	03-33-5000	TRANSFORMER 60 CY GRS TYPE V1 .300 KVA-110V- PR1- 110V- SE F/INSULATING	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 54940 GR7				
0601	03-33-5010	TRANSFORMER, 60 CY GRS TYPE U1, 0.200 KVA, 110V PR1, 90V SEC, TAP 5, 55, 10, 10, 10	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 54950-103 GR72				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0602	03-33-5090	TRANSFORMER, TYPE U, SIZE 1, CLASS B, 60 CYCLE, 330 KVA, PRIMARY 110V, SECONDARIES 115-15, 15 VOLTS, SPEC. AMUS-TR13 AU-207	EA	20	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 54940-007-01				
0603	03-33-5110	TRANSFORMER, 60 CY GRS TYPE U1, 110VPRI-44V SEC. TAP-4-20-20-F GRD. DET.	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 54940-8 GR1				
0604	03-33-5113	TRANSFORMER, TYPE V1, MATCHING, 60 CYCLES, 110 VOLTS.	EA	40	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 54940-008-03				
0605	03-33-5115	TRANSFORMER, U1, PRI. 110V., SEC. 15 V. 20 AMP., FOR TRACK CIRCUITS	EA	20	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		Y P ALSTOM SIGNALING, INC. 54940-005-04				
0606	03-33-5300	TRANSFORMER, 60CY GRS TYPE V CUR-150-PR1	EA	00	00	00
		QPL CODE MFG - NAME MFG - PART-NO				
		N P ALSTOM SIGNALING, INC. 55336GR1				

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0607	03-33-5320	TRANSFORMER, 60CY GRS TYPE V CUR-40A-PR1	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 55336-1GR1							
0608	03-33-6600	UNIT, TEST B1-FOR DC-GRD-DET-12-26V	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		Y P ALSTOM SIGNALING, INC. 58521-003-01							
		Y D NYCTA 733-44-1-B							
0609	03-33-6610	UNIT, TEST B1 FOR DC GRD DET.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 58521-003 02							
0610	03-33-6615	UNIT, TESTER FOR B1-AC GROUND DETECTOR SYSTEM, 110 VAC, 3000/750 OHM UNIT FOR USED WITH AC VANE GROUND DETECTOR RELAY.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 58521-004-01							
0611	03-34-8755	BOARD ASSEMBLY, USED FOR TRAIN IDENTRA STORAGE SYSTEM AT 125TH #ST. & LEX. AVE.	EA		00		00		00
		QPL CODE MFG - NAME MFG - PART-NO							
		N P ALSTOM SIGNALING, INC. 20355-6 GR1							

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE PY2	USE PY1	USE YTD
0612	03-34-8760	BOARD ASSEMBLY, USED FOR TRAIN IDENTRA STORAGE SYSTEM AT 125TH #ST. & LEX. AVE.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	20355-10 GR1		
0613	03-34-8770	BOARD ASSEMBLY, USED FOR TRAIN IDENTRA STORAGE SYSTEM AT 125TH #ST. & LEX. AVE.	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	29041-10 GR2		
0614	03-34-8785	BOARD ASSEMBLY, USED FOR TRAIN IDENTRA STORAGE SYSTEM AT 125TH# ST. & LEX. AVE.,	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	38348 GR2		
0615	03-34-8800	RECEIVER AND FILTER, FOR F-S CARRIER TYPE CODE, USED ON "M" CODE SYSTEM AT 125 TH# ST. & LEX. AVE.,	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	01189-2		
0616	08-60-0000	PROPULSION CONTACT, MALE	EA	00	00	00
	QPL	CODE	MFG - NAME	MFG - PART-NO		
	N	P	ALSTOM SIGNALING, INC.	EC42AD-016		

MATERIAL STANDARDS USAGE REPORT

REC#	STOCK NO	LONG DESCRIPTION	U/M	USE	PY2	USE	PY1	USE	YTD
0622	13-60-7162	CABLE GRIP (SPECIAL ORDER)	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
		MFG - PART-NO							
		26047-03504							
0623	13-60-7163	CABLE GRIP (SPECIAL ORDER)	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
		MFG - PART-NO							
		26047-03506							
0624	13-60-7164	CABLE GRIP (SPECIAL ORDER)	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
		MFG - PART-NO							
		26047-03507							
0625	13-60-7166	CAPTIVE SCREW	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
		MFG - PART-NO							
		30001-03507							
0626	13-60-7167	WASHER, SPECIAL	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
		MFG - PART-NO							
		30011-03514							
0627	14-43-0392	CONNECTOR, SERIAL ALARM CONNECTOR FOR COMMUNICATION INTERFACE UNIT TOD/CBTC	EA		00		00		00
		QPL CODE MFG - NAME							
		N P ALSTOM SIGNALING, INC.							
		MFG - PART-NO							
		TE30006471							

TOTAL PROCESSING TIME = 00 HRS, 00 MINS.

TOTAL RECORDS READ : 631

TOTAL RECORDS PRINTED : 1,438

**** FILES USED ****

MMS --> USE YTD

MMS --> USE PY1, USE PY2

CTF --> LONG DESCRIPTION

VXF --> MFG PART NO

MFG --> MFG NAME

ITEM --> U/M

ALSTSI24 --> STOCK NO

PROGRAM LOCATED : IN ON